


AM180JNHFKH/EU



■ Parts List : AM180JNHFKH/EU

NO	Parts Code	Parts Description	Spec.	Unit	Qt'Y	SA/SNA
1	DB63-03688A	COVER CONTROL	GI-SGCC,T1.0,	PC	1	SA
2	DB64-03127A	CABINET FRAME	GI-SGCC,T1.2	PC	4	SA
3	DB64-03135B	CABINET-COVER	GI-SGCC,T0.8	PC	1	SA
4	DB64-03135B	CABINET-COVER	GI-SGCC,T0.8	PC	2	SA
5	DB64-03136B	CABINET-UP LINK	GI-SGCC,T1.2	PC	1	SA
6	DB64-03135D	CABINET-COVER	GI-SGCC,T0.8	PC	1	SA
7	DB90-08583B	ASSY CABI SIDE-LEFT	ASS'Y	PC	1	SA
7-1	DB61-01282A	HOLDER-SIDE CABI	GI-SGCC,T3.0,	PC	1	SA
7-2	DB64-03128B	CABINET-SIDE LEFT	GI-SGCC,T1.2	PC	1	SNA
8	DB90-08584B	ASSY CABI SIDE-RIGHT	ASS'Y	PC	1	SA
8-1	DB61-01282A	HOLDER-SIDE CABI	GI-SGCC,T3.0,	PC	1	SA
8-2	DB64-03132A	CABINET-SIDE EVAP RH	GI-SGCC,T1	PC	1	SNA
8-3	DB63-03691A	COVER-DRAIN	GI-SGCC,T1.0	PC	1	SNA
9	DB90-08585A	ASSY CABI BODY-LEFT	ASS'Y	PC	1	SA
9-1	DB61-01282A	HOLDER-SIDE CABI	GI-SGCC,T3.0,	PC	1	SA
9-2	DB64-03128A	CABINET SIDE-LEFT	GI-SGCC,T1.2,	PC	1	SNA
10	DB90-08586A	ASSY CABI BODY-RIGHT	ASS'Y	PC	1	SA
10-1	DB61-01282A	HOLDER-SIDE CABI	GI-SGCC,T3.0,	PC	1	SA
10-2	DB64-03130A	CABINET-SIDE FAN RH	GI-SGCC,T1.	PC	1	SNA
11	DB90-08597A	ASSY COVER-PIPE	ASS'Y	PC	1	SA
12	DB94-05128B	ASSY PARTITION	ASS'Y	PC	1	SA
12-1	DB64-03136B	CABINET-UP LINK	GI-SGCC,T1.2	PC	1	SA
12-2	DB67-01487B	PARTITION	GI-SGCC,T1.6	PC	1	SNA
12-3	DB63-03690A	COVER PIPE-SUB	GI-SGCC,T0.8	PC	1	SNA
13	DB98-35054A	ASSY CUSHION RIGHT-SUPPORT	ASS'Y	PC	1	SNA
14	DB98-35055A	ASSY CUSHION TOP-FRONT	ASS'Y	PC	1	SNA
15	DB92-03321B	ASSY PCB MAIN	ASS'Y	PC	1	SA
15-1	DB92-02793A	ASSY FUNCTION	ASS'Y	PC	1	SA
15-2	DB93-12483A	ASSY PCB SUB-EEPROM	ASS'Y	PC	1	SA
16	DB93-09990B	ASSY CONNECTOR WIRE-POWER	ASS'Y	PC	1	SA
17	DB93-11424A	ASSY CONNECTOR WIRE-BLDC	ASS'Y	PC	1	SA
18	DB93-12108C	ASSY PCB SUB	ASS'Y	PC	1	SA
19	DB93-12676B	ASSY-BLDC DRIVER	ASS'Y	PC	1	SA
20	DB93-15340A	ASSY CONNECTOR WIRE-DC SIGNAL	ASS'Y	PC	1	SA
21	DB93-15358A	ASSY CONTROL IN	ASS'Y	PC	1	SNA
21-1	DB27-00093A	COIL CHOKE-REACTOR	13mH,7A	PC	1	SA
21-2	DB39-01108A	CONNECT WIRE-VENTILATOR&WATER HEATER	2,R	PC	1	SA
21-3	DB61-04695A	CASE-EMI	ABS,T2.0,BLACK,5V-A	PC	1	SA
21-4	DB61-06369A	CASE CONTROL	GI-SGCC,T1.0,-	PC	1	SNA
21-5	DB65-00179F	TERMINAL-BLOCK	PBT+G30%,6	PC	1	SA
21-6	DB65-00326F	TERMINAL BLOCK	4P,PBT,4-TAB,4-SCREW,BLK,	PC	1	SA
21-7	DB93-08805D	ASSY CONNECTOR WIRE-EARTH	1,1015,18,YEL	PC	2	SA
21-8	DB93-11423A	ASSY CONNECTOR WIRE-POWER	2,1015,18,BRN	PC	1	SA
21-9	DB93-12674A	ASSY CONNECTOR WIRE-REACTOR	2,1015,18,BR	PC	1	SA
21-10	DB93-13688C	ASSY CONNECTOR WIRE-DC SIGNAL	2,1007,24	PC	1	SA
21-11	DB93-14029A	ASSY CONNECTOR WIRE-DC SIGNAL	6,1007,22	PC	1	SA
21-12	DB95-05009C	ASSY THEMISTOR	10Kohm±3%,103HW,7P,250,UL	PC	1	SA

■ Parts List : AM180JNHFKH/EU

NO	Parts Code	Parts Description	Spec.	Unit	Qt'Y	SA/SNA
22	DB31-00659A	MOTOR BLDC FAN	DL-17860SSBA,1320RPM,310V	PC	1	SA
23	DB90-08544A	ASSY BRACKET MOTOR	ASS'Y	PC	1	SA
23-1	DB61-06385A	BRACKET MOTOR	GI-SGCC,T2.5	PC	1	SA
23-2	DB61-06386A	BRACKET MOTOR-UP	GI-SGCC,T2.0	PC	1	SA
24	DB90-08569A	ASSY CASE FAN-BOTTOM	ASS'Y	PC	2	SA
25	DB90-08570A	ASSY CASE FAN-TOP	ASS'Y	PC	2	SA
26	DB90-08709A	ASSY BRACKET MOTOR-HOLDER	ASS'Y	PC	1	SA
26-1	DB61-06376A	HOLDER-MOTOR	GI-SGCC,T2.0	PC	1	SA
27	DB94-05094A	ASSY BLOWER	ASS'Y	PC	2	SA
27-1	DB60-20011A	BOLT-SPECIAL	L10,M6	PC	2	SA
27-2	DB67-01490A	BLOWER	ABS+GF10%	PC	2	SNA
28	DB94-05310A	ASSY TRAY DRAIN	ASS'Y	PC	1	SA
29	DB96-20644A	ASSY EVAP-MAIN	ASS'Y	PC	1	SA
29-1	DB95-05011H	ASSY THERMISTOR IN	10Kohm±3%,103HW,7P,80	PC	1	SA
29-2	DB96-20620A	ASSY EVAP	ASS'Y	PC	1	SA
29-3	DB96-20787A	ASSY TUBE EVAP OUT	ASS'Y	PC	1	SNA
29-4	DB96-20790A	ASSY TUBE EVAP IN	ASS'Y	PC	1	SNA
29-4-1	DB62-05606A	VALVE GEAR EXPAN	BRASS,6.4,2000,2000	PC	1	SA
29-5	DB81-00635A	SPRING ETC-SENSOR	STS304	PC	2	SA
29-6	DB90-08598A	ASSY CASE EVAP	ASS'Y	PC	1	SNA
29-7	DB61-06380A	SUPPORT EVAP	HIPS(HB),S834S1,BLACK	PC	1	SNA
29-8	DB60-30010B	FASTENER-NUT FLARE	HEX,5/8-18UNF	PC	1	SA
30	DB97-19364B	ASSY ACCESSORY-DUCT	ASS'Y	PC	1	SA
30-1	DB94-03287A	ASSY DRAIN-HOSE JOINT	ASS'Y	PC	1	SA