



5. Exploded Views and Parts List

5-1 Indoor Unit


■ EH035EAV1




■ EH052EAV1/EH070EAV1




5-2 Outdoor Unit





■ UH070EAV1



Ass'y Control Out(cont.)

- UH052EAV1: DB93-05838C
- UH070EAV1: DB93-05838A

